



USEFUL TIPS

The Bait Station is fully assembled. Use this guide to properly attach an accessory to the product.

Carefully un-box the product. To prevent scratching, avoid using sharp blades when removing plastic wrapping. Lay a blanket or soft cloth on your work area to prevent damage during assembly.

Do not to over-tighten hardware. Always check for proper alignment before fully tightening hardware.

TOOLS

» 4mm or 5/32 Allen Key

SAFETY FIRST

Always wear task appropriate protective gear such as OSHA-approved glasses, gloves, work boots, etc. Make sure you have all supplemental materials, including hardware and parts prior to beginning. Always follow instructions. Remember: Improper use of tools or hardware may result in damage to the product or personal injury.

QUESTIONS? CONTACT US.

954-732-6141

AJ@SEAWARDSYSTEMS.COM
SEAWARDSYSTEMS.COM



HARDWARE DETAIL

To help prevent damage to powder coating all hardware **MUST** be installed following the order in our assembly guide.

VERY IMPORTANT: A nylon washer **MUST** always be placed between the powder coat and metal hardware.

TOOLS

- » 4mm or 5/32 Allen Key

LUBRICANT USE

For all hardware, apply a small amount of Anticorrosive Lubricant to the end and the threads.



Attaching an Accessory

HARDWARE

- » Accessory Hardware Bag
(1 bag per accessory)
- » Hardware Detail A

STEPS

- » Align the accessory and product holes.
- » Following hardware detail A, insert the screw from the inside of the product.
- » From the other side of the product, thread the second nylon washer and add a drop of lubricant.
- » Hand-tighten the screw to the accessory.
- » Repeat steps for the second hole.
- » For even tightening, alternate between screws until secure.

