

THE IMPORTANCE OF MAINTENANCE

Regular cleaning and maintenance are vital to ensure the longevity and performance of your SeaWard Systems product. By following the maintenance guidelines provided, you can prevent permanent damage and keep your product in top-notch condition.

Weekly Maintenance

Hose down the product with fresh water to remove any residue, salt, and dirt. This will help prevent build-up and reduce the risk of corrosion.

Monthly Maintenance

Wipe down the product with an all-purpose cleaner. Simply spray the cleaner on the surfaces and wipe it down with a clean cloth. For tougher grime, use a sponge or a magic eraser to scrub the area after applying the cleaner. This will help keep surfaces clean and remove any grime.

RUST STAIN REMOVAL

Some hardware components may start to rust over time. If rust stains begin to run down the painted areas of your product, it is crucial to clean them promptly to avoid permanent damage. Follow these steps to remove the stains:

1 Prepare the Cleaning Solution

Use a commercial rust remover or create a mixture of equal parts white vinegar and water.

2 Apply the Solution

Apply the cleaning solution to the rust-stained area using a cloth or sponge. Allow it to sit for a few minutes to break down the rust.

3 Scrub the Area

Gently scrub the rust stain with a soft-bristle brush or non-abrasive sponge. Do not use metal brushes as they can scratch the surface.

4 Rinse and Dry

Rinse the area thoroughly with fresh water and dry it with a clean cloth.

REPLACEMENT ITEMS

Need to freshen up your SeaWard Systems product, we have replacement hardware and other items available.

Replacement items can be purchased by reaching out to us.

QUESTIONS? CONTACT US.

954-732-6141

AJ@SeaWardSystems.com
SeaWardSystems.com