



### USEFUL TIPS

The Sea Post is fully assembled. Use this guide to properly attach the product to the intended surface.

Carefully un-box the product. To prevent scratching, avoid using sharp blades when removing plastic wrapping. Lay a blanket or soft cloth on your work area to prevent damage during assembly.

Do not to over-tighten hardware. Always check for proper alignment before fully tightening hardware.

### TOOLS

- » Level
- » Drill & Drill Bits
- » Wrench
- » Safety Gloves & Glasses

### CONNECTIVITY

- » 4x4 Pedestal – Water Connectivity
- » 6x6 Pedestal – Water & Electrical Connectivity (Electrician Needed)

### SAFETY FIRST

Always wear task appropriate protective gear such as OSHA-approved glasses, gloves, work boots, etc. Make sure you have all supplemental materials, including hardware and parts prior to beginning. Always follow instructions.

Remember: Improper use of tools or hardware may result in damage to the product or personal injury.

### QUESTIONS? CONTACT US.



[Orders@SeaWardSystems.com](mailto:Orders@SeaWardSystems.com)



## HARDWARE DETAIL

To help prevent damage to powder coating all hardware **MUST** be installed following the order in our assembly guide.

**VERY IMPORTANT: A nylon washer MUST always be placed between the powder coat and metal hardware.**



## MOUNTING HARDWARE

Wood/Composite Surface

- » Lag Screws (4)

Concrete Surface

- » Anchors or Concrete Screws (4)

## 1 Drilling Pilot Holes

### STEPS

- » Position the sea post frame on the mounting surface. If necessary, make sure the mounting surface is reinforced.
- » Mark the position of mounting holes and drill pilot holes for the hardware.

## 2 Securing the Sea Post

### HARDWARE

- » Hardware Detail A

### STEPS

- » Follow hardware detail A.
- » Insert the hardware through the mounting holes and partially tighten into the pilot holes
- » Fully tighten to secure to the mounting surface.

### FINAL CHECK

Check that all hardware is securely fastened and the sea post is stable before use.

